

OPERATING MANUAL

# BE ALIVE

How does it feels to be alive?

ALIVE ONE gives you the unprecedented

orgasm you have never experienced before.

Be alive, for the first time.

— Tony Yau

Inventer & CEO

# JOURNEY TO ECSTASY



Apply moderate amount of lubricant to your erected penis.



Insert your penis into ALIVE ONE.



Long-press POWER button for 2 seconds to turn on.



Press MODE button to start & switch between 10 modes.

## AFTER USE



Remove the vagina cover.



DO NOT use water to wash ALIVE ONE directly.



Pull out the rotating tube with two fingers.



Wash the rotating tube with warm water. Dry gently.

## FUNCTIONS



#### POWER

Long-press to turn power on / off.



### MODE

Long-press to start / pause.

Press to switch between 10 modes.



#### SOUND

Turn moaning on / off.

Click again to switch moaning mode.

\* You must connect your earphone to ALIVE ONE to hear moaning.

## SPECIFICATIONS

Materials ABS Silicone + TPE

Weight 22 oz / 600 g

Size & Dimensions 3.3" X 10.1" / 84 mm X 268 mm

Rechargeable Yes

Charging Port Micro USB Type A

Voltage 110 V - 240 V

Max. Charge Time 2.5 Hours

Battery Size 1500 mAh

Max. Battery Life 2 Hours

Max. Noise Level 35 dB

Waterproof Level IPX4

## MAINTENANCE INSTRUCTIONS

- 1. Do not use water to clean ALIVE ONE™ directly.
- 2. To clean, pull the rotating tube out from the masturbator and wash carefully.
- 3. Do not carry out any maintenance or repair work other than that shown in this ALIVE ONE™ operating manual.
- 4. Always disconnect the plug from USB charging port before inspecting for problems.
- 5. If the appliance does not work:
- Check if the USB charging port has electricity supply
- Check that the USB charging cable is correctly inserted into the USB port.

# SAFETY INSTRUCTIONS

- 1. Read and follow all instructions. All operating and user instructions should be followed
- 2. When the ALIVE ONE<sup>TM</sup> is plugged in to a charging source with the USB charging cable, never use it in the shower to prevent risk of electric shock.
- 3. Protect the USB charging cable from being pinched, particularly at the connectors.
- 4. Unplug the USB charging cable during lightning storms or when unused for long periods of time.
- 5. Do not place ALIVE ONE™ near any heat sources such as radiators, stoves, or other apparatus that produce heat.
- 6. Do NOT make unauthorized alterations to ALIVE ONE™.
- 7. Use ALIVE ONE™ only with an agency approved power supply which meets local regulatory requirements (e.g., UL, CSA, VDE, CCC) in accordance with the specifications.
- 8. Do NOT place naked flame sources, such as lighted candles, on or near ALIVE ONETM.

# CUSTOMER CARE

Thank you for choosing ALIVE ONE™.

- 1. After registering your free 2 year warranty, your ALIVE ONE™ will be covered for 2 years from the date of purchase, subject to the terms of the warranty.
- 2. If you have any questions about your ALIVE ONETM, contact us with your details of where / when you bought your ALIVE ONETM.
- 3. Visit www.alivemasturbator.com/contact.html for online help, support articles, general tips and useful information about ALIVE ONE™.

# REGISTER AS AN ALIVE ONE OWNER

To help us to ensure you receive prompt and efficient service, please register as a ALIVE  $ONE^{TM}$  owner:

Visit www.alivemasturbator.com/warranty.html

Enter your telephone number and submit. This will confirm the ownership of your ALIVE ONE<sup>TM</sup>.

## LIMITED 2-YEAR WARRANTY

#### What is Covered?

Our warranty covers defects in materials and workmanship of ALIVE  $ONE^{TM}$ .

## How Long Is my warranty?

ALIVE ONE $^{\text{TM}}$  is covered by standard two (2) years One time product replacement warranty.

#### What is Not Covered?

Our warranty does not cover any damage, deterioration or malfunction resulting from any alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, exposure to fire, improper packing and shipping ( such claims must be presented to the carrier )

#### What We Will Do?

If during the warranty period the product fails, with a replacement fee, an identical or equivalent replacement item will be shipped to the customer.

### Limitation of Liability

The maximum liability of ALIVE Adult Toys, Inc. under warranty shall not exceed the actual purchase price paid for the product. To the maximum extent permitted by law, ALIVE Adult Toys, Inc is not responsible for direct, special, incidental or consequential damages resulting from any breach of warranty or condition, or under any other legal theory.

#### Other Conditions

This limited warranty gives you specific legal rights, and you may have other rights which vary from country to country or state to state.

## DISPOSAL INFORMATION

- 1. ALIVE ONE™ is made from high grade recyclable materials. Recycle where possible.
- 2. This product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.
- 3. To return your used device, please use the return and collection systems. They can take this product for environmentally safe recycling.



